



Cisco® 675 and 678 Modem

How to Set Up Port Forwarding

*Note: Qwest® High-Speed Internet Technical Support can't support this feature.
You must know the port to be mapped and the protocol.
To get that information, contact the software manufacturer
of the program that you are trying to configure.*

1. At a cbos> prompt, type in "en". Select **Enter**.
2. Select **Enter** again for the password.
3. At the cbos# prompt, type in **set nat entry add** (IP address of the PC) (Port to be mapped) (Packet type TCP or UDP). Then select **Enter**.

```
cbos> enable <Enter>
Password:

cbos#set nat entry add (IP address of the PC) (Port #) (TCP or UDP)
<Enter>
cbos#write <Enter>
cbos#reboot <Enter>

cbos#
```