



**Qwest® Advanced Networking Modem:
2-Wire® 2700 HG**

How to Set Up the Modem Manually

Use this document if:

- You need to configure your modem with your ISP-provided information.

This document assumes:

- You use the Qwest Advanced Networking Modem with Wireless: 2-Wire 2700 HG.
- You have an Ethernet (wired) connection to the Internet.

1. Enter "192.168.0.1" in the Address bar of your Internet browser to open the "Network at a Glance" Web page.
2. Select the **System** icon. Then, select **Advanced Configuration Settings**.



3. Type in your **Username** and **Password**.

Confirm the **No Credential Required** box is not checked.

Then, select the **SAVE** button.

PPP Mode

Connection Type:

Username:

Password:

Confirm Password:

No Credentials Required:

My ISP does not require a username and password

Addressing:

DHCP

Static

IP Address:

Unnumbered Mode

Gateway IP Address:

Subnet Mask:

VIP:

WARNING: Unchecking VIP will disable the ability to use devices on the LAN with dynamic IP addresses.

RFC 1483 Mode

Connection Type:

Addressing: Dynamic

Static

IP Address:

Subnet Mask:

Default Gateway:

Host (Optional):

Domain (Optional):

DNS Server: Automatically obtain DNS settings

Specify DNS Server settings

Primary DNS:

Secondary DNS (Optional):

Domain Name (Optional):

SAVE



4. The "SET UP COMPLETE" confirmation screen will appear. Your modem is now configured.

