

## Actiontec® 1520 and 1524

### How to Check your Modem Status

1. Open your Web browser (Microsoft® Internet Explorer or Netscape®). In the location or address bar, type **192.168.0.1**. Select **Enter**.
2. Select **Status**.



- This screen shows your Internet connection status, and the IP address and DNS Server IP addresses you're using.

**Actiontec™**

[ Main ] [ Setup ] [ **Status** ] [ Utilities ] [ Help ]

**General Status**  
Routing Table  
WAN Status  
LAN Status  
Active User List

### Current Status

**Firmware Version:** 1.60.10.0.69-R1524SU

**MAC Address:** 00:20:E0:0E:31:39

**WAN**

Connection: **Connected**

Mode: **PPPoA**

IP Address: **63.230.63.230**

Subnet Mask: **255.0.0.0**

Gateway: **67.41.63.230**

DNS #1: **207.108.224.1**

DNS #2: **204.147.80.5**

**LAN**

IP Address: **192.168.0.1**

Net Mask: **255.255.255.0**

DHCP Server: **on**

Copyright 2001-2002 Actiontec Electronics Inc.