


Accton® DSL 1000 Modem

How do I view my modem settings?

1. Open your Web browser (e.g., Microsoft® Internet Explorer or Netscape®). In the location or address bar, type **192.168.1.1/mmadv/advindex.htm**. Then, select **Enter**.



2. Now you can view the modem settings on the “advanced” page.