



Cisco® 675 and 678 Modem

How to Set the EXEC Password

1. At a cbos> prompt, type **en** and select **Enter**.
2. Select **Enter** again for the password.
3. At the cbos# prompt, type **set password exec**. Then type in the password you'd like and select **Enter**.

```
cbos> enable <Enter>
Password: <Enter>
cbos# set password exec "password" <Enter>
Exec Password Change Successful!
```

4. Your password is now set.