

Intel® PRO/DSL 2100 Modem

How to Connect to the Internet RFC 1483 Bridged Configuration

Windows® ME

1. Double-click on the **Connection Manager** icon in the bottom right corner of your screen to launch the Connection Manager (which connects and disconnects your high-speed Internet service).



2. Your Connection Manager screen should resemble the picture below when you're connected to the Internet. Click **Connect** if you are not already connected.

