

SPEED CALLING 8

Dialing your most frequently called numbers is fast and easy with SpeedCalling 8. Simply make a list of the 8 numbers you want to program, and assign each one a single-digit code from 2 to 9.

TO PROGRAM



Then enter a one-digit code + phone number, including any necessary area code or access code. Example: *74 + Code 2 + area code 602 + 7-digits 555-1234

TO DIAL



Example: Code 2 + # dials 555-1234

Please refer to the back for more detailed instructions.

1 800-244-1111 for customer assistance
qwest.com

HOW TO USE SPEED CALLING 8

- Make a list of your 8 most important or frequently dialed numbers.
- Assign each a one-digit code from 2 to 9.
- Lift the receiver and press ***74**.
- Press the one-digit code you've selected, followed by the telephone number assigned to that code.

Include your access code and/or area code if it's a long distance number.

- You'll hear a tone to let you know the number is programmed.
- Repeat these steps for the other seven numbers.

TO CALL SOMEONE ON YOUR SPEED CALLING LIST

- Press the code (2-9) you gave to that person, followed by the **#** key.

TO CHANGE A PROGRAMMED NUMBER

- Repeat the first 5 steps above. You don't need to reprogram the numbers you want to keep.

FOR ROTARY PHONES

If you are using a rotary telephone instead of a touch-tone, dial **1174** (instead of ***74**), then dial the code you gave to the number you want to call, without the **#**. The phone will hesitate a moment, then dial the number.

SPEED CALLING 30 GIVES YOU MORE.

If you find you have more than 8 important numbers you want to program, you may want to try Speed Calling 30 instead. Speed Calling 30 easily adds 30 more numbers to your speed dialing list!

Measured service and long distance charges may apply for all completed calls. Optional services are not available in some areas.

Copyright © 2005 Qwest. All Rights Reserved.

SC8_C 07/04